


BLOWER SLB260

Item	Part No.	Description
3	BL2-3	Fan cover
5	BL2-5	Spring
9	BL2-9	Stop wire
11	BL2-11	Throttle lever
17	BL2-17	Impeller
18	BL2-18	Rear Cochlea case
20	BL2-20	Connect cover
21	BL2-21	Front Cochlea case
22	BL2-22	Fuel tank
32	BL2-32	Inlet fuel pipe
33	BL2-33	Filter cleaner
35	BL2-35	Throttle wire component

Item	Part No.	Description
42	BL2-42	Blower tube A
43	BL2-43	Blower tube B
S	BL2-S	Starter assembly



Picture for illustration purposes only.



26CC ENGINE (to suit SLB260)

Item	Part No.	Description
Coil Component		
47	EN1-5	Airfilter base assembly
50	EN1-3	Filter element
51	EN1-2	Airfilter outter cover
52	EN1-1	Airfilter cover screw
Carburettor Assembly		
40	EN1-13	Inlet manifold gasket engine side
42	EN1-12	Inlet manifold
43	EN1-10	Gasket carby side
44	EN1-19	Carburettor assembly
Starter Assembly		
37	BL2-S	Starter assembly
Muffler Assembly		
1	EN1-52	Muffler screw
3	EN1-30	Heat insulator washer
7	BL1-7	Muffler
8	BL1-8	Muffler gasket
Magneto Starter Assembly		
6	RCJ6Y/BPMR7A	Spark plug
14	BL1-14	Coil assembly

Item	Part No.	Description
Connecting Shaft		
24	BL1-24	Impeller connecting shaft
Engine Cylinder Components		
17	EN1-54	Cylinder base gasket
18	EN1-55	Piston rings / set
19	EN1-56	Piston
20	EN1-59	Gudgeon pin
21	EN1-61	Gudgeon pin circlip
Crankcase Components		
22	EN1-58	Stop ring
23	EN1-60	Gudgeon pin bearing
28	EN1-30	Washer
29	EN1-34	Oil seal 12 x 22 x 7
30	EN1-31	Crankcase front
33	EN1-33	Crankcase casket
34	EN1-57	Flywheel key
35	EN1-36	Crankshaft / conrod assembly
36	EN1-37	Rear half crank case

