


Hedge Trimmer SLHT600

Item	Part No.	Description
Gear Assembly		
10	HT2-10	Gear case inside lid
11	HT2-11	Gear case front felt seal
12	HT2-12	Gear case gasket
26	HT2-26	Gear case
28	HT2-28	Needle bearing
42	HT2-42	Gear case lid
43	HT2-43	Left handle connect
46	HT2-46	Throttle cable
47	HT2-47	Spacing cover
48	HT2-48	Knob camp
49	HT2-49	Right handle connect
50	HT2-50	Grease nipple
52	HT2-52	Damping seat
53	HT2-53	Damping cover
54	HT2-54	Bracket
Protecting Handle		
8	HT2-8	Protecting handle



Picture for illustration purposes only.

Item	Part No.	Description
Blade		
4	HT2-4	Blade cover
9	HT2-9	Blade end protection
32	HT2-32	Blade support bracket
33	HT2-33	Safeguard
34	HT2-34	Blade settle plate
35	HT2-35	Blade
39	HT2-39	Nylon lock nut
Handle Assembly		
1	HT2-1	Handle right side (A)
2	HT2-2	Handle left side (B)
5	HT2-5	Stop switch assembly
18	HT2-18	Handle cover seat
19	HT2-19	Safety lever
20	HT2-20	Throttle trigger



26CC ENGINE (to suit SLHT600)

Item	Part No.	Description
Air Filter Components		
51	EN1-1	Air filter cover screw
50	EN1-2	Air filter cover
49	EN1-3	Air filter
47	EN1-5	Air filter cover base
Carburettor Components		
6	EN1-13	Cylinder side gasket
7	EN1-12	Inlet manifold
8	EN1-10	Carburettor side gasket
46	HT1-46	Carburettor assembly
Clutch Components		
26	EN1-19	Clutch assembly
Ignition Coil Components		
19	EN1-25	High voltage wire
22	EN1-26	Ignition coil
Crankcase Components		
3	EN1-30	Washer
31	EN1-31	Front half crankcase
32	EN1-37B	Rear half crankcase
33	EN1-33	Crankcase gasket
34	EN1-34	Oil seal 12 x 22 x 7
35	EN1-35	Ball bearing 6001/P5
36	EN1-57	Crankshaft / flywheel key
43	EN1-36	Crankshaft / conrod assembly
Starter Components		
45	HT1-45	Starter assembly
61	EN1-15	Screw M4 x 16

Item	Part No.	Description
Starter Pawl Components		
44	HT1-44	Starter pawl assembly
Fuel Tank Components		
52	EN1-62	Fuel cap assembly
53	HT1-53	Fuel tank
57	EN1-73	Fuel tank filter
58	EN1-74	Fuel tank grommet
Spark Plug		
18	RCJ6Y/BPMR7A	Spark plug
Engine Cover Components		
15	EN1-44	Cover
16	EN1-45	Engine cover
Muffler Components		
10	EN1-51	Muffler
11	EN1-52	Screw M5 x 55
12	EN1-50	Muffler gasket
Engine Cylinder Components		
3	EN1-30	Washer
1	EN1-53	Cylinder
2	EN1-54	Cylinder base gasket
37	EN1-55	Piston rings / set
38	EN1-56	Piston
39	EN1-60	Gudgeon pin bearing
40	EN1-59	Gudgeon pin
41	EN1-58	Stop ring
42	EN1-61	Gudgeon pin circlip

